


PARTS

RESULT



DORR HÖUZZER™

TRIM LESS DOOR FRAME
ASSEMBLY INSTRUCTIONS

www.DorrHouzzor.com



Questions?

Feel free to contact us at
Info@DorrHouzzor.com | 844.MYDORRS | 844.693.6777

Copyright © 2019 | Dorr Houzzor USA, LLC | All rights reserved.

HARDWARE



A

FRAME TO CORNER KEY SCREWS
3/4" #8 self-tapping Phillips head screw (included with frame)

16 PER FRAME



B

ALUMINUM FRAME FLANGE TO 18-GAUGE WALL STUDE SCREWS
#8 x 1" self-tapping clear zinc (included with frame)

28 PER FRAME



C

HINGE TO WOOD DOOR SCREWS
1 1/2" Phillips head wood screws (included with hinges)

4 PER HINGE



D

HINGE TO ALUMINUM FRAME SCREWS
6 x 1-5/8" (3.5 x 41mm) self tapping clear zinc (included with frame)

4 PER HINGE



E

MAGNETIC CATCH TO FRAME SCREWS
3/4" #6 self-tapping Phillips head screw (included with frame)

2 PER FRAME



F

LATCH TO WOOD DOOR SCREWS
5/8" #6 Phillips head wood screws (included with frame)

2 PER DOOR



G

HINGE COVER PLATES SCREWS
3/8" Phillips head machine screws included with hinges

4 PER HINGE

STEPS

- 1) Remove hardware from the box and sort by type.
- 2) Please check to see that all hardware and parts are included prior to start the assembly.
- 3) Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.

